



# NC-VP-PBS

## Nurse Call Patient Bed Station Vandal Proof Call Jack Station

### BENEFITS

- Reliable Signaling
- No Maintenance
- Low Power
- Simple Wiring
- Easily Integrates to other Systems
- Attractive Station Hardware

The Tech Works **NC-VP-PBS** is a call for HELP Station with a ¼ inch call cord jack and a Vandal Resistant Push button with concentric Call Assurance Light built in to the button and mounted on a rugged stainless-steel plate. The call cord jack is provided for activating the Normal or Bed Call directly at the station. Call cancel is a Lighted Button to reset the station. The reset can be either local or a remote key switch or a remote lighted push button.

An integral call confirmation LED notifies the user that a call has been sent. The Call Assurance Light will be Off if no call is pending, glowing steadily if a Normal Call is pending, and flashing if an Emergency Call is pending.

This is a passive button and light assembly designed for use with active stations like the **NC-DL-12-R** Dome Light. Screw Terminals provide wiring connection to the active electronic stations that provide signaling and control for the **NC-VP-PBS**.

Mounting is a standard 1-gang electrical box. The Face Plate is made of 12-gauge Stainless Steel with a brushed finished and includes tamper resistant mounting screws.

### Associated Equipment

<b>PBC-7</b>	Push Button Cord 7 ft.
<b>NC-DL-12</b>	Dome Light
<b>VPKS-1</b>	Vandal Proof Key Switch
<b>VPBL-1</b>	Vandal Proof Button/Lite

### Design Information

<b>Power</b>	15V DC
<b>Color</b>	Stainless Steel
<b>Mounting</b>	1 Gang Back Box
<b>Dimensions</b>	3.25" W x 0.5" D x 5" H
<b>Weight</b>	1 lb.

### Architects' and Engineers' Specifications

The Nurse Call System Patient Bed Station shall be a standard one gang electrical box mounting device constructed of Vandal Resistant Stainless Steel. A ¼ inch phone jack shall be included to place a Patient Bed Call to the System. A remote Cancel button shall be provided to reset the station. A call confirmation light shall be included to indicate that a call has been placed. The staff station shall be a passive electronic device requiring no more than 3 mA at 15 Volts DC for full operation.

The Nurse Call System Patient Bed Station shall be Tech Works Model NC- VP- PBS



## Tech Works®

*"Making Specialized Communication Easy"*

